







Item # 366-135

Instructions Castaldo



Product Specifications

Cure type: Platinum Uncured Viscosity: 8,500 cps Hardness Shore A: 43

Tensile Strength: 3.5 N/mm² (508 ppi)

Elongation at break: 370% Tear Strength: 9 N/mm² (108 ppi)





Ready to use molds in as little as 30 minutes!

Please read and observe the following instructions carefully. Read Material Safety Data Sheet before using.

- 1. Components MUST BE WEIGHED CAREFULLY AND NOT ESTIMATED. Use an accurate scale. DO NOT MEASURE BY VOLUME. DO NOT ESTIMATE. DO NOT GUESS! Make sure both parts are at room temperature.
- 2. Stir individual components before use. Pour the equal amounts of parts A & B into a mixing container, preferably one with a rounded bottom. Do not use a rubber mixing bowl as the rubber may inhibit the cure (See "incompatible materials", below). Mix ratio is 1:1 by weight.
- 3. Always pour rubber (part B) into catalyst (part A).
- 4. Mix thoroughly by hand or machine for 1 to 2 minutes until a uniform color is achieved. Take care to scrape the sides of the mixing bowl into the center several times during mixing.
- 5. Make sure the bowl is big enough to allow for temporary expansion of the rubber of 300% to 400% during vacuuming without overflowing. Wide mouth containers allow more air to escape during vacuuming than narrow mouth containers.
- 6. Vacuum the liquid rubber for 3 to 4 minutes, making sure that it boils and bubbles vigorously. Vacuuming is complete once the rubber rises and collapses.

No Vacuum? No Problem! Use your wax injector instead! See page 2

- 7. Do not over-vacuum. Make sure to allow extra room at the top of the frame for the rubber to expand during vacuuming.
- 8. Working time before cure begins is approximately 10 minutes at room temperature.
- 9. Put the mold aside to cure at room temperature ($77 \text{ F}^{\circ}/25 \text{ C}^{\circ}$) for 60 to 90 minutes, depending on temperature. Always remember that longer cure times will improve the mold and will not hurt it, while shorter cure times will result in soft and deformed molds. Avoid curing in areas where the temperature is below 650 F /18 o C.

Avoid moving the mold during the curing process.

Cure at the same temperature that all your materials were when they were mixed. Temperatures below 65°F/ 18°C will lengthen the time required for proper curing and may spoil the mold.

NOTE: Rubber received during extremely cold winter months may require warming before use regardless of the temperature of your work room because long exposure to cold will keep the rubber cold for extended periods. If necessary, warm part A & part B separately to 100°-130°F/ 37°- 54°C for several hours. Check rubber temperature with a thermometer and allow to cool before using. Remember that slight increases in cure temperature will create low levels of shrinkage





10. If you need the mold to be finished faster, it can be cured for 30 minutes by warming it to 120°F /50°C as it cures. Typical devices for this warming process include the tops of vulcanizers, food warming trays, slow cookers, rice cookers, radiators, empty wax injectors, etc. Immersion in warm water works well. Avoid higher temperatures, which might damage the mold.

Typical Mold Sizes, Mixing Proportions & Volume

The following is only a guide -— the mass of your model will increase or decrease the amount of rubber needed. Sizes given are for typical 1 7/8 inch x 2 7/8 inch (4.8 cm x 7.3 cm) molds.

Mold		Thickness	Appr	oximate	Total	Weight	Needed	
0.75"/	19	mm	2.6	OZ.	/	75	grams	
1.00"/	25	mm	3.8	OZ.	/	110	grams	
1.25"/	32	mm	4.6	OZ.	/	130	grams	
1.50"/ 38 mm			5.3 o	z. / 150 g	rams			



No Vacuum Pump ??

You can cure the mold inside your empty and unheated air-pressure type wax injector, using the pressure to collapse air bubbles rather than a vacuum to remove them.

Simply place the mold frame with the uncured liquid rubber inside an unheated wax injector pot with the heat turned off, pressurize it as high as it will go, and let it cure under pressure.

If your wax injector is empty you can heat the pot to 120 o F $\!\!/$ 50 o C and cure the mold in as little as 30 minutes.

If you don't have either a vacuum pump or a wax injector, you can brush the uncured liquid rubber on the model with an artists' paint brush and examine the model for air bubbles.

Pop any bubbles that you see with a pin, knife point or similar object.

Similarly, you can merely dip the model in the liquid rubber, shake off any excess and then examine it for air bubbles as described above.

With either technique, place the model after it is coated with liquid rubber in a standard liquid rubber mold frame and fill it with more rubber. Any air bubbles in the part of the mold away from the model are not a problem.

STORAGE: Keep containers tightly closed. Store at normal room temperatures.

Parst A & Part B will remain usable for at least one year from the date of shipment if stored in unopened containers. Rubber more than one year old may be made usable again by thoroughly mixing each component separately before use.

CLEANING MOLDS: Castaldo LiquaFast molds can be cleaned if they become soiled or dirty by washing them with ordinary soap and water. Use a small brush if needed.





MODEL PREPARATION: Porous surfaces such as wood, terra cotta or plaster must be sealed to prevent the rubber from penetrating the pores. Spray polyurethane, several coats of paste wax, allowed to dry and then polished, or melted paraffin, petroleum jelly and potters soap all work well for certain surfaces.

INCOMPATIBLE MATERIALS: Certain materials will inhibit the cure of Castaldo LiquaFast, leaving areas that are soft and sticky. Included are sulfur containing compounds such as latex gloves and tubing, wood, PVC, natural & organic rubber such as neoprene. Also avoid epoxy, Mystic® tape, Scotch® tape, vinyl electrical tape, acid & rosin core solder and tin-cured silicone rubbers such as Dow Corning RTVs. This is not a complete list. If in doubt, always make a test mold first.

CLEAN UP: If mixed rubber has spilled or is left on tools, simply wait for the rubber to cure and pull it off surfaces it has adhered to. There is no known acid or solvent that will remove it. If rubber has lodged in jewelry models and cannot be otherwise removed, heating with a torch to above 600° F/ 312° C will burn the rubber and allow it to be cleaned off as ordinary ash/ carbon scale. Use adequate ventilation. Uncured rubber can be wiped off with paper towels and then washed off with ordinary soap and water.

MOLD RELEASE: Mold release agents are not normally needed. Do not use silicone oil sprays.

DISCLAIMER: The information contained in this bulletin is considered accurate. However, no warranty is expressed or implied regarding the accuracy of the data, the results to be obtained by the use thereof, or that any such use will not infringe any patent. Before using, user shall determine the suitability of the product for the intended use and user assumes all risk and liability whatsoever in connection therewith.

PROBLEM	CAUSE					
Mold won't cure - soft & sticky	Improper mix ratio; not mixed properly Too cold Individual components not mixed thoroughly before use					
Rubber remains liquid, soft & sticky in places	See "Incompatible Materials", above-					
Large area of uncured rubber in center of mold	Unmixed rubber added at end of pour					
Mold cures too slowly	Improper mix ratio Cure temperature too low Individual components not mixed thoroughly before use					
Mold distorts after handling or use	Cure temperature too low Mold removed from frame or cut too soon					
Streaks of soft rubber or air bubbles	Rubber not mixed thoroughly. Unmixed rubber usually from the bottom or sides of mixing bowl					
Bubbles in mold	Insufficient vacuuming of uncured rubber Temperature changes during curing					





IMPORTANT NOTICE: All Castaldo Jewelry Manufacturing Products are intended for professional use only and only by persons familiar with jewelry casting techniques. We are not responsible for misuse of our products or their use in conjunction with unsafe or improperly maintained equipment.

Castaldo products are warranted to be free from defects in material and workmanship. THE FOREGOING WARRANTY IS IN LIEU OF AND EXCLUDES ALL OTHER WARRANTIES NOT EXPRESSLY SET FORTH HEREIN, WHETHER EXPRESSED OR IMPLIED BY OPERATION OF LAW OR OTHERWISE, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. The seller shall not be liable for incidental or consequential losses, damages or expenses, directly or indirectly arising from the sale, handling or use of the goods, or from any other cause relating thereto, and Seller's liability hereunder in any case is expressly limited to the replacement (in the form originally shipped) of goods not complying with this agreement or at Seller's election, to the repayment of, or crediting Buyer with, an amount equal to the purchase price of such goods, whether such claims are for breach of warranty or negligence. Any claim by Buyer with reference to the goods sold hereunder for any cause shall be deemed waived by the buyer unless submitted to Seller in Writing within thirty (30) days from the date Buyer discovered, or should have discovered, any claimed breach.

Copyright © 1991-2014 F.E. Knight Inc. ALL RIGHTS RESERVED